Marking





Approbations Specification

EAC

L351

Type Size: S2

Classification Contact: Rigid contact bridge

Classification Contact Mat: Silver Classification Terminal: Bolt terminal

area insulation Vo	oltage Ui					
			Voltag	e(V) AC/DC		
				690 AC		
ated impulse with	hstand voltage Uimp					
Voltage (kV)	Overvoltage category	Pollutio	on degree Supply	system		Function
6		3	Valid fo	or lines with grounded common neutral t	termination	Switch / Switch disconnector
ated uninterrupte						
Current (A)	Ambient tempe	, ,	Peak temperature (°C)	additional requirements		
350		55	60	Ambient temperature +55°C during 2	24 hours with peaks up to +60°C	
ated operational o						
tilization category	/			Voltage (V)		Current
C-20A				20 - 690		
C-21B				220 - 440		2
C-21B				500 - 500		
C-21B				660 - 690		
ated operational p	power					
tilization category	/		Voltage (V)	No. of phases	No. of poles	Power (k
C-23B			220 - 240	3	3	
C-23B			380 - 440	3	3	
C-23B			500 - 500	3	3	1
C-23B			660 - 690	3	3	
lax. Fuse rating IE	EC					
use characteristic	;			N	lo. of Fuses	Current
R					1	4
JL60947-4-1 ,	, UL508					
	-					
ated insulation vo	-	_	Voltac	e (V) AC / DC		
	-		Voltag			
ated insulation vo	oltage Ui		Voltag	e (V) AC / DC 600 AC		
	oltage Ui	Current (A		600 AC	Additional Text	
ated insulation vo	oltage Ui	Current (A)	600 AC Ambient temperature (°C)	Additional Text	
ated insulation vo	oltage Ui	Current (A,)	600 AC	Additional Text 	
ated insulation vo	oltage Ui)	600 AC Ambient temperature (°C)		
ated insulation vo	oltage Ui rent)	600 AC Ambient temperature (°C)		
ated insulation vo	oltage Ui rent			600 AC Ambient temperature (°C) 0 - 40		
ated insulation vo	oltage Ui rent)	Ambient temperature (°C) 0 - 40 e (V) AC / DC		
ated insulation vo	oltage Ui rent oltage Ui			600 AC Ambient temperature (°C) 0 - 40		
ated insulation vo	oltage Ui rent oltage Ui	350)) Voltag	600 AC Ambient temperature (°C) 0 - 40 e (V) AC / DC 600 AC		
ated insulation vo	oltage Ui rent oltage Ui	350 Current (A,	Voltag	Ambient temperature (°C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (°C)		
ated insulation vo	oltage Ui rent oltage Ui	350 Current (A, 350	Voltag	600 AC Ambient temperature (°C) 0 - 40 e (V) AC / DC 600 AC	- Additional Text	
ated insulation vo	oltage Ui rent oltage Ui	350 Current (A, 350	Voltag	Ambient temperature (°C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (°C)	- Additional Text	
ated insulation vo	oltage Ui rent oltage Ui rent CHNICAL INFORMA	350 Current (A, 350	Voltag	Ambient temperature (°C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (°C)	- Additional Text	
ated insulation vo	oltage Ui rent oltage Ui rent CHNICAL INFORMA	350 Current (A, 350	Voltag	AC Ambient temperature (*C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (*C) 0 - 40	- Additional Text	tightening torque (Ib
ated insulation vo	oltage Ui rent oltage Ui rent CHNICAL INFORMA	350 Current (A, 350	Voltag	AC Ambient temperature (*C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (*C) 0 - 40	- Additional Text	tightening torque (lb
ated insulation vo	oltage Ui rent oltage Ui rent CHNICAL INFORMA	350 Current (A,	Voltag	AC Ambient temperature (*C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (*C) 0 - 40 (Nm)	- Additional Text	
ated insulation vo	oltage Ui rent chnical informa	350 Current (A,	Voltag	AC Ambient temperature (*C) 0 - 40 e (V) AC / DC 600 AC Ambient temperature (*C) 0 - 40 (Nm)	- Additional Text	



EHE

CE marking

UK Directives

IEC 60047 2: FN 60047 2: VVE 0660 Toil107

IEC 60947-3; EN 60947-3; VDE 0660 Teil107



UL 60947-4-1; CSA C22.2 No. 60947-4-1



CSA C.22.2 No.14



Power loss per pole

Power (W) 15,50

Conditions during transport and storing

Minimum temperature (°C)

Maximum temperature (°C)

40

Maximum temperature (°C)

85

In case of temperatures below -5°C no shock load permissible

General Information

Text

- Cable lug or copper bus must accept M12x20 screw.
- Terminals with factory fitted jumper links are tightened during production for loss prevention. When opening the terminal clamps, make sure that no factory fitted links get lost and that all wire connections are properly seated.
- After wiring, ALL terminal screws must be tightened to the specified torque values.
- The protection class of the selected mounting type may vary if optional extras are used.
- Do not lubricate or treat contacts.
- Switches may only be mounted, connected and set into operation by qualified persons according to the accepted rules of technology.
- After installation of the switches the spacings between the terminals must be sufficient to fulfill the requirement of the applicable standards.

 Operating temperature

 Min. Temperature [°C]
 Max. Temperature [°C]

 -25
 60